



B = buffer plates for the belt

A = buffer plates for under part of the counter-blow hammer

hammer type	A / B	pieces	a	b	c	d	e	f	g	h
DGH 3	B	18	250	100	82	35	9	10	7	22
	A	3	205	70	50	35	9	20	7	22
DGH 4	B	18	260	105	87	40	9	12	9	26
	A	3	225	80	60	40	9	25	9	26
DGH 6	B	18	310	105	87	40	9	12	9	26
	A	3	250	90	70	40	10	25	9	26
DGH 8	B	18	335	120	97	40	10	12	9	26
	A	3	280	90	70	40	10	25	9	26
DGH 10	B	18	380	135	112	45	10	15	11	30
	A	3	315	100	80	45	10	28	11	30
DGH 13	B	22	390	150	127	45	10	15	11	30
	A	3	340	100	80	45	10	28	11	30
DGH 16	B	22	440	170	147	45	10	15	11	30
	A	4	385	110	85	45	12	28	11	30
DGH 20	B	22	470	182	162	45	10	15	11	30
	A	4	435	110	85	45	12	28	11	30
DGH 25	B	22	530	205	182	50	10	18	13	35
	A	4	470	120	95	50	12	32	13	35
DGH 30	B	22	570	220	196	50	12	18	13	35
	A	5	530	120	95	50	12	32	13	35
DGH 35	B	22	590	220	196	50	12	18	13	35
	A	5	560	120	95	50	12	32	13	35
DGH 40	B	22	615	220	196	50	12	18	13	35
	A	5	590	120	95	50	12	32	13	35
DG 8	B	18	360	135	112	45	10	15	11	30
	A	3	315	100	80	45	10	28	11	30
DG 10	B	18	390	150	127	45	10	15	11	30
	A	3	315	100	80	45	10	28	11	30
DG 13	B	22	440	170	147	45	10	15	11	30
	A	3	340	100	80	45	10	28	11	30
DG 16	B	22	470	182	162	45	10	15	11	30
	A	4	385	110	85	45	12	28	11	30
DG 20	B	22	470	182	172	45	10	15	11	30
	A	4	435	110	85	45	12	28	11	30
DG 32	B	22	615	270	236	50	15	32	15	34
	A	5	590	120	95	50	12	32	13	35

Buffer plates for hammer up to 100 Mpm blow work on request.